



ND 40




Washbasin mixers ND40



42214551; 41214541 with pop-up




41214642



41214651; 41214641 with pop-up


Shower mixers ND40




41216604; 41216634 with hand-shower



41217504





41213123 41213133 with shower




41209355; 41209395 with shut-off


Kitchen mixers ND40



41209555; 41209595 with shut-off




41209495; 41209491 with hand-shower



41209455; 41209451 with hand-shower

Bide mixer



41214571

